

Standard 3-Season Sunroom under a Dura-Fold

Installation Instructions for a 3-Season Room, Deluxe Screen Room or Full Screen Room under a Dura-Fold Roof

1. Install the Dura-Fold Roof according to existing directions without Joiner Panels.
2. After the roof is installed, pick front of roof up about 3" higher than the height of the front wall. For example: for 76-1/2", go to 80". For 82" go to 85".
3. Hold the roof in place with 2 x 4's placed under Front Support.
4. Slide the Ball of the Front Wall Adapter into the Post Track of the Front Support.
5. Refer to Assembly and Installation Instructions for: 3-Season Sunroom Enclosure, Deluxe Screen Room and Full Screen Room. According to which one you are installing.
Do not forget to cut the angle on the Gable End Channel.
6. Slowly lower one side of the roof, so the Front Wall Adapter goes over the top of the front wall.
7. Slowly let the rest of the roof down over the front wall. Then secure the Front Wall Adapter to the Wall Panel Frame sections in place with #8 x 1/2" screws.
8. Now finish the Gable Ends as per instructions for your room. See Step 5.

